
QR CODE FUNCTION AND SETTINGS

1. QR function


With this function, after the QR code is scanned, the file will be imported automatically and the mark points will be scanned for cutting. The manual import process is omitted, and different materials can be placed together. The camera will automatically identify different QR codes to import different files and improve efficiency.



2. SETTINGS

Open a web or software which is used to create the QR code. Then input the name of your file to create the QR code. Because after the camera scanning the QR code, it will automatically find your file by the name.






When you need to print the material, this is the size we usually use and recommend

6mm

10mm






Choose the right path of your files. Need to choose contain subfolders. The X direction offset is 25 mm as recommend before.



After all the settings are set, open the camera and move to the right position, click the QR icon. Then it will automatically input the file and cut.



Setting video